









10:23:00am

Time of Day: Set in configuration menu

Wed 2/25/2015

Date: Set in configuration menu

5.0v

Active voltage setpoint: Adjust using up/down arrows or select a different preset using right/left arrows.



Physical output: When illuminated red, there is power at the clip cord. When grey, output is off. The number indicates which preset is active and the green arrow indicates which button was used to acquire the current preset.



Input Status: This indicates if and which method of input was used to activate the output; this is very handy for troubleshooting a bad foot switch. "Toggle" indicates that pedal toggle mode is active for the currently active preset.

SESSION/RUN TIME

01:45:00/\$250.00

Session / Run Time: Indicates the "Session Time" based on stop watch inputs or "Run Time" based on actual power to the tattoo machine. User must enter config menu to select which method to use for billing as well as set the hourly rate to be calculated.

Hertz 120

Coil machine speed in cycles per second

Duty: 50%

Coil machine percent on time within one cycle

Settle: Front contact switching quality as a percentage of on time

Amps: 0.45

Machine current draw in Amps



10:23:00am Wed 2/25/2015

5.0v

SESSION TIME
01:45:00/\$250.00

10:23:00AM Wed 2/25/2015

5.0v

Hertz: 120
Duty: 50%
Settle: 4%
Amps: 0.45

SESSION TIME
01:45:00/\$250.00

10:23:00am Wed 2/25/2015

5.0v

SESSION TIME
01:45:00/\$250.00

10:23:00am Wed 2/25/2015

5.0v

SESSION TIME
01:45:00/\$250.00

10:23:00am Wed 2/25/2015

5.0v

SESSION TIME
01:45:00/\$250.00

Hertz: 120
Duty: 50%
Settle: 4%
Amps: 0.45

10:23:00am Wed 2/25/2015



Hertz: 120
Duty: 50%
Settle: 4%
Amps: 0.45

5.0v



Time: Sets the time of day

Date: Sets the calendar date

Preset Count: Sets the quantity of available voltage presets associated with each of the Left and Right arrow buttons

Output: Allows the user to enable the right, left, or both physical outputs. This governs how the preset buttons are associated with the physical outputs.
XR-D Only

JumpStart: This setting assigns the jump start function to the individual preset buttons with the options Right, Left, and Both. (JumpStart sends an initial 12 Volt pulse to help start those hard starting machines.)
XR Only

Refer to "Basic Operation" page for XR-D Jump start configuration.

Key Clicks: Allows user to Enable/Disable the audible beep sound during button presses.

Meter: Allows user to set hourly rate between 1 and 999 units per hour for use in session/run time calculations

Locale: Allows user to change the currency symbol. (currently only US and EU.)



the 1990s, the number of people in the UK who are aged 65 and over has increased from 10.5 million to 13.5 million (15.5% of the population).

There is a growing awareness of the need to address the needs of older people in the UK. The Department of Health (1999) has published a strategy for older people, which sets out a vision for the future of health care for older people. The strategy is based on the following principles:

- Older people should be able to live independently in their own homes for as long as possible.
- Older people should be able to access the services they need to live well.
- Older people should be able to participate in decisions about their care and services.

The strategy also sets out a number of key objectives for the future of health care for older people:

- To reduce the number of older people who are admitted to hospital.
- To reduce the length of stay of older people in hospital.
- To reduce the number of older people who are admitted to care homes.
- To reduce the number of older people who are admitted to residential care.

The strategy also sets out a number of key actions for the future of health care for older people:

- To improve the quality of care for older people.
- To improve the access to services for older people.
- To improve the participation of older people in decisions about their care and services.

The strategy also sets out a number of key challenges for the future of health care for older people:

- To address the needs of older people who are living in poverty.
- To address the needs of older people who are living with long-term conditions.
- To address the needs of older people who are living with mental health problems.

The strategy also sets out a number of key messages for the future of health care for older people:

- Older people are a diverse group and their needs vary.
- Older people should be able to live well in their own homes for as long as possible.
- Older people should be able to access the services they need to live well.
- Older people should be able to participate in decisions about their care and services.

The strategy also sets out a number of key actions for the future of health care for older people:

- To improve the quality of care for older people.
- To improve the access to services for older people.
- To improve the participation of older people in decisions about their care and services.

Warranty

Critical Tattoo warrants your product to be free from defects in material and workmanship for a period of 2 years from the original date of purchase. If you discover a defect in a product covered by this warranty, we will repair the item or if repair is not possible, replace the item. Proof of purchase in the form of a sales receipt must be provided for warranty repair. If your power supply or foot pedal is beyond the 2 year warranty period, repair options are still available. Repair work does not reset the warranty period. Warranty is valid only when sold through authorized sales channels. Third party resellers such as Amazon and Ebay are not authorized sales channels. Please call for details.

Exclusions: This warranty covers defects in manufacturing discovered while using the product as recommended by the manufacturer. The warranty does not cover loss or theft, nor does coverage extend to damage caused by misuse, abuse, unauthorized modification, improper storage conditions, lightning, or natural disasters. The warranty does not cover parts that are subject to normal wear and tear, such as power adapters and power cords, and clip cords (Power adapters are covered for 6 months after purchase date).

Limits of Liability: Should the product fail, your sole recourse shall be repair or replacement, as described in the preceding paragraphs. We will not be held liable to you or any other party for any damages that result from the failure of this product. Damages excluded include, but are not limited to, the following: lost profits, lost savings, lost data, damage to other equipment, and incidental or consequential damages arising from the use, or misuse of this product. In no event will Critical Tattoo be liable for more than the amount of your purchase price, not to exceed the current list price of the product, excluding tax and shipping charges. Critical Tattoo disclaims any other warranties, express or implied. By installing or using the product, the user accepts all terms described herein.

If you did not purchase your product directly from Critical Tattoo, be sure to go to criticaltattoo.com and register for the best customer service in the industry.

